

TOPLINE ASSEMBLY INSTRCUTIONS

TOPLINE TXE WASH TANK.

This attachment will fit the Topline TXE 505 & 252 machines. Instructions on how to use this attachment are detailed below.

OPERATING INSTRUCTIONS

YOUR NEW TOPLINE TXE WASH TANK IS FITTED AND READY TO USE.

- 1. Tip the tank back to reveal the underside of the machine. If there is any line marking fluid present in the tank, be careful when doing this so as to avoid spillages and wastage of line marking fluid
- 2. The tap assembly is located underneath the tank and is attached to the rear of the pump filter.
- 3. To operate the Topline TXE machine from the main tank ensure that the silver tap (Paint line tap), located on the tank line, is in the on position whilst ensuring that the water line tap is in the off position see Fig 1. When either of these taps are in the on position, the tap-operating lever will be in line with the tap i.e. the operating lever will be parallel with the tap.
- 4. To flush the system simply turn the paint line tap to the off position and the water line tap to the on position see Fig 2 and continue spraying until the water runs clear from the spray head.

MAINTENANCE

- 1. Use Supaflush in the wash tank to further improve the cleaning process and prolong the life of your machine.
- 2. On a monthly basis remove the wash tank from the machine and wash thoroughly to remove any algae build up. To do this simply slacken the P clip holding the tube in place see Fig 1 and gently pull the tank away from the machine until the fitting is exposed and you are able to remove the tube from the wash tank. When complete, push the tube firmly back into the wash tank fitting and pull the tube back through the P clip so that the wash tank is tight against the front of the cover and retighten the P clip down to secure the tube back in place, ensuring that the large tube sleeve is gripped by the clip.



