

Spreader Settings

To help with the accurate application of your fertilizer dressings

These recommended spreader settings are given for a walking speed of approximately 5km/hr. These settings are for guidance only.

Exact rates, using the settings here, cannot be guaranteed – rates depend on the spreader itself and the accuracy of the operator. Calibrate the spreader at regular intervals, including effective spreading width.

Drop Spreader Settings for SS-2 Single Pass at FULL RATE

Spreader	Type	Amount of Product Applied (g/m ²) After One Pass										
		5	10	15	20	25	30	35	40	45	50	55
Greenmaster Pro-Lite	All Analyses		3¾	4	4½	5	5¼	5½	6	6¼	6½	
Sportsmaster	All Analyses (not including CRF Range)		3¾	4	4½	5	5¼	5½	6	6¼	6½	
SierraformGT	All Analyses		3¼	3¾	4¼	4¾	5¼	5¾	6¼	6½		
STEP Hi-Mag	Trace Elements	2	2¾	3½								
H2Pro	Granules		3¾	4¼	4¾							

Drop Spreader Settings for Classic Drop Spreader Single Pass at FULL RATE

Spreader	Type	Amount of Product Applied (g/m ²) After One Pass										
		20	25	30	35	40	45	50	55	60	65	70
SierraformGT	All Analyses	4		5	6							
Sierrablen Plus	All Analyses				6.75		7.25					
Sierrablen	All Analyses				13.0		14.5			12.5 (x2)		
H2Pro	Wetting Agent	6.25										



SPREADER TABLE FOR ICL SPECIALTY FERTILIZERS ROTARY SPREADERS: ACCUPRO 2000 / SR 2000

Product name	Cone Setting	Effective width (m)	Spreader settings at FULL RATE dosage gram/m ² for single pass application												
			5	10	15	20	25	30	35	40	45	50	55	60	
Greenmaster Pro-Lite	6	3.7						M	N						
H2Pro granules	5	4.0		J	K½	M									
ProTurf	6	5.0				K	L	L½	M						
Sierrablen	4	4.7					Q	R½	T½	V	X	Q (x2)	R (x2)	R½ (x2)	
SierrablenPlus	4	4.8				N	O	P	R	S	T				
SierrablenGT	6	3.7		I½	K	L	M	M½							
Sportsmaster	4	3.7			L	M	N	O½	P½	Q	R	S	T	U	
Sportsmaster CRF	3	5.0				Q	R½	Y½							
Sportsmaster CRF Mini	4	4.8				N	O	P	R						
Sportsmaster Base	6	3.5							N½	O	O½	P			
Step Hi-Mag	7	4.3	H	I½	K½										
Product name	Cone Setting	Effective width (m)	Spreader settings at HALF RATE dosage gram/m ² for double pass application												
			5	10	15	20	25	30	35	40	45	50	55	60	
Greenmaster Pro-Lite	6	3.7						J½	K						
H2Pro granules	5	4.0		H½	I	J									
ProTurf	6	5.0				I	I½	J	J½						
Sierrablen	4	4.7					M	N	O	O½	P	Q	R	R½	
SierrablenPlus	4	4.8					L	M	M½	N	N½				
SierrablenGT	6	3.7			H	I½	J½	K							
Sportsmaster	4	3.7						L	L½	M	M½	N			
Sportsmaster CRF	3	5.0				M½	O	O½							
Sportsmaster CRF Mini	4	4.8				K½	L	M	M½						
Sportsmaster Base	6	3.5							K½	L	L½	M			
Step Hi-Mag	7	4.3	G½	H	I										

The spreader settings are guidelines only. For latest spreader setting always consult our website: www.icl-sf.com. The spreader should be calibrated prior to application to ensure accuracy. The spreader settings are based on a walking speed of 5 km/hour. Walking faster or slower than 5 km/hour will alter the spread width and application rate. Exact rates are dependent upon the spreader itself and the accuracy of the person operating it.



www.icl-sf.com



AccuPro One Spreader Settings

Product	Rate (g/m ²)	Slider plate	Spread width (metres)	Single pass at FULL RATE	Double pass at HALF RATE
Landscaper Pro Spring & Summer	25	Closed	2	12	8
Landscaper Pro Autumn & Winter	30	Closed	2	13	9
Landscaper Pro Autumn & Winter	35	Closed	2	14	10
Universtar Balance	25	Closed	2	12	-
Universtar Balance	30	Closed	2	13	10
Universtar Balance	40	Closed	2	14	11

These settings are for guidance only. Exact rates, using the spreader settings here, cannot be guaranteed - rates depend on the spreader itself and the accuracy of the operator. Calibrate the spreader at regular intervals.

